

PRE-PRINTED PET MATS

Part # DM241 / DM242 / DM243

Sublimation Instructions

These pet mats are part of the DrySubMates line of products which are made of a soft, stain resistant, felt-like fabric with a non-abrasive, waterproof backing. They have been pre-printed with various designs with a space for you to add your personalized touch. When heat pressed, this product does not emit the offensive odor usually associated with similar mouse pad-type materials.

Designing and Pressing Instructions:

Create an outline for your artwork that's 1/16" larger than the imprint area. Templates can be found on our website as well. After it's printed, cut out the artwork just inside the outer border.

In order to keep the transfer in place during pressing and to eliminate any tape marks, the repositionable adhesive spray is recommended. Cover the entire mat with blow-out paper or clean Teflon to keep the ink dyes off of your heat platen.

Preheat press to **400°**. Adjust pressure to **Medium**. Press for **60 seconds**.

Equipment needed:

Standard Flat Heat Press, Teflon Sheet(s), Repositionable Adhesive Spray, Blow-out Paper

Sublimation Directions:

1. Lay a Teflon sheet on the bottom of your heat press. (This is to prevent the rubber backing on the mat from sticking to blow-out paper or the bottom platen of the press when heated).
2. Spray the transfer with a very light mist of Repositionable Adhesive Spray and attach it to the blank imprint area.
3. Place your product face up on your Teflon already on the heat press.
4. Cover entire mat with blow-out paper or a second sheet of clean Teflon.
5. After pressing for the allotted time, open the press.
6. Allow product to cool before removing the Teflon and transfer paper. (Failure to do so could cause the backing to tear).

